

### Caution

- ◆ Always Unplug the charger from the power source when not in use
- ◆ Check that the wall outlet you are using is within the AC 100 - 240V range
- ◆ Do not place the charger on heated seats or against other heat sources
- ◆ Do not attempt to replace any part of the charger on your own
- ◆ Do not expose the charger to liquids or excessive heat
- ◆ Do not use any corrosive cleaning substances on the charger
- ◆ Keep out of reach from children

## 7-Port USB Charging Station User Reference Guide



### Key Features & Benefits

- ◆ Clean up your workspace by rapidly charging 7 devices with one outlet
- ◆ SmartFlow: Recognizes your connected devices and delivers the most efficient and safe charge to devices of any size or make
- ◆ Multiple protections against over-heating, over-charging, and power surges
- ◆ Safely hold devices with anti-scratch cradles
- ◆ On / Off switch allows you to save energy when device is not in use
- ◆ Charge your tablets, smartphones, and any other USB powered devices
- ◆ UL certified power adapter. Charger meets FCC, CE, and RoHS Specifications

★ For optimal charging speed, we recommend using your device's original USB cords.

### Specifications

Port	7 USB Charging Ports
Input	AC 100~240V / 50-60Hz, 2A
USB Output	2.4A (Max.) / per port Total: DC 5V / 15A (Total output capacity)
Power	DC 19V / 4A, 76W (Max.)
Each Interval Space	0.75"
Size	7.48" (W) x 2.63" (H) x 5.51" (D)
Weight	13.4oz
Operating Temperature	32F ~ 104F
Storage Temperature	-4F ~ 185F

### Package Contents

- ◆ 7-Port USB Charging Station
- ◆ Power Adapter
- ◆ AC Power Cord
- ◆ User Reference Guide

### Product Layout




Figure 1: 7-Port USB Charging Station

Outside diameter (OD)	Inside diameter (ID)	Plug length (L)	Negative / Positive
5.5(mm)	2.5(mm)	12(mm)	-- ⊖ + ★ Center pin for positive voltage and the outer shield for negative voltage

Table 1: Power Plug Specifications




Figure 2: Power Adapter & AC Power Cord

- ◆ **ON / OFF button:** Press to turn on / off the charging station.
- ◆ **USB Charging Port (x7):** Connect here to charge smartphones, tablets and other USB-powered devices.
- ◆ **Power Jack:** Connects to power adapter with AC power cord.

#### Power Jack:

Refer to below table for the specifications of the power adapter.



### Instructions for Use

1. Insert the 2-prong female of the AC power cord into the power adapter.
2. Insert the power plug of the adapter into power jack of the charger station.
3. Plug the 2-prong male connector into a 110V-240V wall outlet.
4. Verify the green LED on the power adapter is lit to ensure it's receiving power.

5. Remove two films of anti-slip pad located on the bottom of the charger station, then press it firmly into place.



Figure 3

6. Press **ON/OFF** button to power on the charger station, and verify the blue LED is lit.
7. Plug your USB cables into USB charging port to charge your USB-power devices.
8. Remove two films of anti-slip pad located on the surface of the charger and place your USB-power device into space.



Figure 4

### Application

7-Port USB Charging Station is for home and business use. It enables charge of up to 7 USB-power devices simultaneously, keeping them organized and convenient.



Figure 5

### Troubleshooting

If the charger station isn't functioning properly:

- ◆ Check that the charger station is plugged into a functioning wall socket.
- ◆ Check that the green LED on the power adapter is lit to ensure that it is receiving power.
- ◆ Check that the USB cord is firmly inserted into both the charger station and your USB device.
- ◆ Check that the total wattage for all connected USB devices is under 65W.
- ◆ Check that the power of the charger is on.